

Contactors 10

Table of contents

CONTACTORS AND CONTROL RELAYS



CONTACTORS
5 HP TO 25 HP
Pages 1605-1618



CONTACTOR ACCESSORIES
Pages 1606, 1613-1617




POWER CONTACTORS
30 HP TO 400 HP
Pages 1619-1629



REVERSING & STAR-DELTA CONTACTORS
Pages 1624-1627, 1648-1652




LIGHTING CONTACTORS
Pages 1630-1634



MINI CONTACTORS
Pages 1635-1654

THERMAL OVERLOAD RELAYS




Pages 1679-1689

MANUAL MOTOR STARTERS



Pages 1690-1701

MOTOR CONTROLS & PROTECTION



Pages 1656-1657

CONTACTORS & CONTROL RELAYS

Approvals and marine classifications	1602
Coils , spares, high power contactors	1628
Contactors and control relays ,	
low power, compact,	
4 to 18.5 kW / 5 to 25 HP	1605-1618
Accessories and system components	1606, 1613-1617
Auxiliary contacts	1613, 1615
Auxiliary modules	1617
Ordering information	1604, 1618
Technical details	1667, 1669, 1671-1672
Contactors and control relays, mini	1635-1654
AC operated	1636-1637, 1642-1643, 1647-1649, 1652
DC operated	1638-1640, 1644-1646, 1650-1651
Accessories and components	1635, 1641, 1653,
Auxiliary contacts	1641, 1653
Coil suppressors	1641, 1653
Ordering information	1604, 1654
Reversing contactors	1648-1652
Technical details	1664-1666
Contactors, high power	1620-1629
22 to 270 kW / 30 to 400 HP	1620-1621
Accessories and components	1623, 1627-1628
Auxiliary contacts	1622
Coils, spares	1628
Ordering information	1604, 1629
Reversing contactors,	
4 to 63 kW / 5 to 75 HP	1624

Star-delta contactors,	
7.5 to 500 kW / 10 to 670 HP	1625-1627
Technical details	1668, 1670, 1672
Contactors for switching lamps and transformers, selection guide	1662
Definitions ,	
characteristics of switchgear	1600-1601
Dimensions	1673-1678
Fusing of squirrel cage motors ,	
guide values	1659-1660
General information	1604-1605
Lamp and transformer	
switching contactors, selection guide	1662
Lighting contactors	1630-1634
110-120 VAC	1630, 1634
220-240 VAC	1630, 1632
Selection guide, lamp switching	1631, 1633
Mini contactors	See Contactors and control relays, mini
Motor controls/protection	1656-1657
Ordering information , general	1604
Overview selection guide	1597-1598
PVC insulated cables and wires , ratings	1661
Reversing contactors	1624, 1648-1652
Specifications, how to read	1596
Standards, contactors and control relays	1663
Star-delta contactors	1625-1627
Technical details ,	
contactors and control relays	1664-1672

MANUAL MOTOR STARTERS

Accessories	1691-1694
Applications, typical	1701
Circuit diagrams	1700
Dimensions	1700-1701
Overview	1690-1691
Selection tables	1692, 1695
Short-circuit breaking capacity	1695
Technical details/specifications	1697-1699
Terminal capacities	1696
Thermal overload protection,	
PVC insulated leads	1696
Trip curves	1696

THERMAL OVERLOAD RELAYS

Accessories	1684
Approvals	1603
Dimensions	1688-1689
General information	1684-1686
Overview	1597
Specifications	
Use with compact contactors	
DL 4K-DL 18K	1682
Use with mini contactors	
KL 2, KL 4	1680-1681
Use with power contactors	
DL 22-DL 270	1683
Technical details	1687